



User Manual Book

Chest Freezer

Preserva Series

MD 0318 WD, MD 0558 WD

MD 0758 WD

TABLE OF CONTENT

Part 1: Safety Information	4
Environmental Notice	6
Part 2: Name of Parts	7
Part 3: Quick Start Guide	8
Installation	8
Before First Use	8
Control Panel	9
Freezing Fresh Food	10
Storing Frozen Food	10
Thawing	11
Tips on Freezing Foods	11
Tips on Storing Frozen Foods	11
Part 4: Maintenance	12
Cleaning and Maintenance	12
Defrosting	13
LED Lamp Replacement	13
Part 5: Troubleshooting	13
Part 6: Specification	15

This guide book explains everything you need to know about your new product. Please contact our Customer Care should you need further assistance through www.modena.com.

PART 1: SAFETY INFORMATION

Read the user manual book carefully!

- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- Do not damage the refrigerant circuit.
- When positioning the appliance, ensure the supply cord is not trapped or damaged.
- The refrigerant and insulation blowing agent inside the refrigerator need special disposal procedure. Consult the disposal method with related department
- Do not locate multiple portable socket-outlets or portable power supplies at the rear of the appliance. Do not use plug adapter.
- To avoid hazard due to instability of the appliance, it must be fixed in accordance with the instructions.
- Opening the door for long periods of time can cause a significant increase of the temperature in the compartment of the appliance
- Clean the surfaces that come in contact with food and accessible drainage systems regularly
- Do not store hot foods into the freezer. Wait until it cools down to room temperature.
- Store foods in suitable containers in the refrigerator, so that it is not in contact with or drip onto other foods.
- If power outage occurs, unplug the power cord. Wait at least 10 minutes before starting the appliance to avoid damage to the compressor.


- If the refrigerating appliance is left empty for a long period of time; switch it off, defrost, clean, dry, and leave the door open to prevent mould from developing within the appliance
- While carrying and positioning the fridge, do not damage the cooler gas circuit.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- If the socket does not match the refrigerator plug, it must be replaced by the manufacturer, a service agent or similarly qualified persons in order to avoid a hazard.
- If the supply cord is damaged, it must be replaced by the manufacturer, an authorized service agent or similar qualified persons, in order to avoid a hazard.
- Children aged 8 years or older, people with limited physical, sensory, mental capabilities, and people who have no experience, can use the appliance safely after they have been given the appropriate supervision or instruction concerning use of the appliance.
- This Freezer can be used for household or similar applications such as:
 - Staff kitchen areas in shops, offices, and other working environments
 - Farm houses and by clients in hotels, motels, and other residential environments
 - Bed & breakfast type environments
 - Catering and similar non-retail environments

Environmental Notice



The packaging material used is recyclable. We recommend that you separate plastic, paper and cardboard and give them to recycling agents. To help preserve the environment, the refrigerant used in this product is iso-butane (R600a) or propane (R290), which does not affect the ozone layer and has little impact on the greenhouse effect. According to WEEE (Waste of Electrical and Electronic Equipment) guidelines, waste from electrical and electronic devices should be collected separately. If you need to remove of this appliance in the future, do not throw it away with the rest of your domestic garbage. Instead, please take the appliance to the nearest WEEE collecting agents, where available.

PART 2: NAME OF PARTS



1. Door
2. Basket
3. Cabinet
4. Control panel
5. Caster wheels

**Above picture is for reference only. Difference between the picture and actual product may occur*

***Feature and equipments differ by each product*

PART 3: QUICK START GUIDE

Installation

1. Before first use, leave the appliance for 1 hour to stabilize the refrigerant
2. Install the freezer on even and sturdy surface. Uneven surface may cause objects in it to fall.
3. Provide adequate space for air circulation between the freezer and the wall or other objects. Back and side clearance is 10 cm, and top clearance is 70 cm.
4. Do not put freezer near heat sources such as stove, ovens, boilers, etc.
5. Do not put freezer under direct sunlight or exposed to rainwater to avoid electrical current leakage
6. Ensure that the voltage and frequency match the freezer specification, which are 220 V and 50 Hz.
7. Do not use cord extension or branched outlet since it poses risks of shortage, overheating and fire.
8. If the unit must be installed in a humid environment, make sure to install a circuit breaker to avoid shortage.

WARNING!

The power plug must be easily accessed and unplugged after installation

Before First Use

1. Before using the freezer for the first time, open the freezer door for a while to provide good air circulation before use
2. Clean the interior and accessories using lukewarm water and neutral soap to eliminate bad odor typical from newly manufactured product. After that, dry before use.
3. Please wait 30 minutes before turning on the freezer. Oil in the compressor may circulate to the refrigerant system during the transportation or distribution process

- When turning the freezer for the first time, cabinet may become warm and the compressor will operate in a very long time to achieve ideal temperature. Upon reaching the ideal temperature, the thermostat will stop the compressor and the freezer will operate normally
- Do not put foods into the freezer before the ideal temperature is reached

WARNING!
Do not use detergent or abrasive cleaners as it will damage the product finishing

Control Panel



- Freezing indicator
- Fast Freeze indicator
- Temperature display
- Increase temperature
- Decrease temperature
- Fast Freeze button
- Celsius/Fahrenheit button
- Power button
- Set button

Control Panel Instructions:

1. Temperature adjustment: Press Set button (9) until the temperature display flashes, then press + (4) or – (5) button to change the value. Press Set button (9) again to exit and save. If no button is pressed after 6 seconds, the temperature will be displayed again.
 2. Turn On: Press and hold the Power button (8) for 1 second until the temperature display shows the temperature value.
 3. Turn Off: Press and hold the Power button (8) for 3 seconds until the temperature display shows "-- --".
 4. Freezing Indicator: When the appliance is running, this light will turn on. When the target temperature is reached, this light will turn off
 5. Celcius/Fahrenheit button: Press this button to switch between Celcius and Fahrenheit unit.
 6. Fast Freeze: Press and hold the Fast Freeze button (6) for 1 second until the Fast Freeze indicator (2) is turned on. To stop fast freeze function, press and hold the Fast Freeze button (6) for 3 seconds until the Fast Freeze indicator (2) is turned off.
- Check the temperature after 4 (four) hours. If the temperature has reached the desired level, you may use start using the freezer.
 - The temperature will be affected by:
 - Ambient/room temperature
 - Door open frequency
 - Quantity of food stored inside
 - To reach the desired temperature, all the above factors must be considered, and a few adjustments may be needed.

Freezing Fresh Food

Freezer is suitable for freezing fresh food and storing frozen food for a long period of time. Place fresh foods on the bottom of the compartment.

Storing Frozen Food

When you want to start the freezer after a long time, adjust the thermostat to highest level and wait until 2 (two) hours before storing anything inside the freezer.

IMPORTANT!

If accidental defrosting occurs (for example in power outage), defrosted foods must be consumed or cooked immediately. Cooked foods can be re-frozen.

Thawing

Frozen food can be thawed in a fridge compartment or at room temperature. Small pieces of frozen food may be cooked directly, but the cooking time will increase.

Tips on Freezing Foods

- The freezing process takes 24 hours. Do not add foods into the freezer during this period.
- Freeze top quality, fresh, and thoroughly cleaned foods.
- Prepare the foods in small portions to make it freeze faster and can be thawed in the required quantity.
- Wrap the foods with aluminum foil or polyethylene and make sure it is airtight.
- Do not allow fresh unfrozen food to touch other frozen food. This is to avoid a rise of temperature of the frozen foods.
- Lean foods freeze better and can be stored longer than fatty foods. Salt can help preserve the foods.
- Consuming ice cubes immediately from the freezer may result in frost burns.
- It is recommended to label each individual package with storing date to keep tab of the storage period.

Tips on Storing Frozen Foods

- Make sure that the commercially frozen foods were adequately stored by the retailer.
- Be sure that the frozen food is quickly transferred to the chest freezer in the shortest amount of time.
- Do not open the door too frequently or leave it open for a long period of time.

- Do not exceed the storage period indicated by the food manufacturers.

PART 4: MAINTENANCE

Cleaning and Maintenance

To make sure that the freezer is in optimum condition, the interior and accessories must be cleaned regularly.

IMPORTANT!

Freezer may not be connected to the main electrical socket during cleaning! Risk of electric shock!

- Before performing cleaning activity, switch off the freezer and unplug the power cord.
- Do not clean the freezer using steam cleaner. Moisture from the steam may damage the electrical components and cause electric shock. Hot steam may damage plastic components. Freezer must be dried completely before use.

IMPORTANT!

Essential oils and organic solvent may damage plastic components. For example lemon water, orange water, butyric acid, cleaner that contains acetic acid.

- Do not allow such substances to come in contact with the appliances.
- Do not use abrasive cleaners.
- Remove the foods from the freezer and store in a cool and well covered place.
- Clean the interior and accessories using cloth and lukewarm water. After that, clean with clean water and dry completely.
- Dust can accumulate on the condenser and cause performance drop. Clean the freezer condenser at least once a year using soft brush or vacuum cleaner.

- After everything is dried completely, install the accessories and freezer to the initial position.

Defrosting

Freezer will become progressively covered with frost and must be cleaned. Do not use sharp metal objects to scrape the frost because it can damage the freezer. Use plastic scraper.

If the accumulated frost becomes very thick, complete defrosting should be performed as follows:

- Unplug the unit. Remove the inner drain plug. Open the door and let it open to accelerate the defrost process. Defrosting usually takes a few hours.
- To collect the defrost water, place a tray beneath the outer drain hole.
- Pull the outer drain dial and rotate 180°. The defrost water will flow out of the freezer.
- When finished, push the outer drain plug back to its place. Reinstall the inner drain plug. Monitor the water level in the tray to avoid overflow.
- Clean the interior of the freezer and plug the power cord.
- Adjust the thermostat knob to the desired position.

LED Lamp Replacement

If your freezer is equipped with LED lamp, contact Service Center for lamp replacement. LED lamp replacement must be performed by qualified technician.

PART 5: TROUBLESHOOTING

Check the following before contacting our Service Center in the event of malfunction

WARNING!

Before troubleshooting, unplug the unit from power source. Only a qualified technician is allowed to perform troubleshooting not stated in this manual.

IMPORTANT!

There are some normal sounds during use (compressor sound, circulating refrigerant sounds)

Problem	Possible Cause	Recommended Action
Appliance does not work	<ul style="list-style-type: none">• Power cord is unplugged or loose• Blown fuse or damaged fuse• Defective socket	<ul style="list-style-type: none">• Insert power cord correctly• Check the fuse, replace if needed• Malfunction must be repaired by qualified electrician
Appliance is not cold	<ul style="list-style-type: none">• Thermostat not properly adjusted• Too much food• Door is opened frequently• Freezer is placed in hot area• Bad ventilation• Frost accumulated inside the freezer	<ul style="list-style-type: none">• Adjust the thermostat until it's cold• Rearrange or reduce the food• Do not open the door too frequent• Place freezer in a cool and dry place• Ensure adequate ventilation• Defrost and clean the freezer
Appliance is too cold	<ul style="list-style-type: none">• Thermostat adjusted to maximum position	<ul style="list-style-type: none">• Adjust the thermostat with lower setting
Dew outside of freezer	<ul style="list-style-type: none">• Ambient temperature and humidity too high	<ul style="list-style-type: none">• Place freezer in a cool and dry place
Loud noise	<ul style="list-style-type: none">• Freezer is touching the wall or other object• Freezer pipe is touching other parts	<ul style="list-style-type: none">• Reposition the freezer and follow the minimum distance• If needed, bend the pipe to avoid touching with other objects

PART 6: SPECIFICATION

MODEL	MD 0318 WD	MD 0558 WD	MD 0758 WD
Capacity (Liter)	315	530	750
Power Input (Watt)	210	380	310
Color	White	White	White
Control panel	Digital	Digital	Digital
Basket (pcs)	1	1	1
Refrigerant	R600a/68g	R290/95g	R290/105g
Rated Current (A)	1.2	3.2	4.0
Rated Voltage (V)	220-240	220-240	220-240
Rated Frequency (Hz)	50	50	50
Product dimension (WxDxH)(mm)	1120×640×860	1606×755×900	1836×855×900
Product weight (kg)	42	71	83

*) S = Stainless, R = Red, C = Cream, O = Orange, N = Green, U = Blue, W = White, V = Silver, G = Grey, L = Black

Design and specification can change without prior notice to improve the quality of the product. The illustration in this manual is schematic and can be different with your actual product. The values on label or in other documents are according to laboratory test and relevant standards. Values can vary depending on the actual operational and environmental condition of the product.

09/21



PT MODENA INDONESIA
Jl. Industri Raya I Blok D-8,
Jatiuwung, Tangerang 15135